


# S & K TV Systems

## Cable Box/Remote Operation instructions

### High Definition Box (TVS 5000)



#### **Operation:**

Turn on TV and Cable Box.

Tune the channel number using the number pad or channel up/down buttons. Refer to printed listing on back of this card.  
*Optional: Press Guide or OK button to access Program Guide or Channel listing. Choose your channel by navigating through guide or channel listing. Hit select to tune channel. (You can hit exit at any time to stop navigation and tune the channel number using the number pad or channel up/down buttons.)*

#### **Trouble shooting:**

##### **TV is on but there is no picture:**

No lights on cable box – Make sure box is plugged into a working power outlet.

Turn box on using power button on the front left corner of the box.

Time and flashing red light on cable box – Turn on cable box using "Cable" power button on remote.

Program # & solid red light & flashing green light on box – Check to see if coax connector is

Connected tightly to wall outlet and RF input on box.

Program # & solid red & green lights on box – Verify TV is on the correct video input (\_\_\_\_\_) use

Input button on the remote to cycle through available inputs.

Check HDMI (or 5 wire Component) connection from cable box to TV for tightness.

Replace cables if necessary.

##### **TV has a frozen picture (or you have verified the steps above and still have no picture):**

Power cycle the cable box – Turn the cable box off using the power button on front left corner of box.

Leave off for 30 seconds.

Turn the Cable box on using the power button on front left corner of box.

Allow 1 minute to start up.

Allow 30 minutes for all guide data and program information to reload.

If you are still having problems contact our office at 1-800-924-7880.

Broadcast Basic \$44.95			Expanded Basic \$90.99 - Includes Broadcast Basic & Digital Music					
Channel #		Channel Name	Channel #		Channel Name	Channel #		Channel Name
SD	HD	Name	SD	HD	Name	SD	HD	Name
2	<b>102</b>	WGN	26	<b>126</b>	ESPN	53	<b>153</b>	Travel Channel
3		FOX - KQDS	27		ESPN-2	54		TV Land
4	<b>104</b>	CBS - WCCO	28		ESPN Classic Sports	55		TLC
5	<b>105</b>	FOX - WEUX	29		ESPN News	56		Hallmark Channel
6		Me TV	30		Big Ten Network	57		Hallmark Movies and Mysteries
7	<b>107</b>	PBS WHWC	31		FSN - Wisconsin	58		Spare (future use)
8		Wisconsin Channel	32	<b>132</b>	NFL Network	59		Turner Classic Movies
9		Create	34	<b>134</b>	Golf Channel	60	<b>160</b>	USA
10	<b>110</b>	ABC - WQOW	35	<b>135</b>	Fox Sports One	61	<b>161</b>	Syfy Channel
11	<b>111</b>	CW	36	<b>136</b>	NBC Sports	62	<b>162</b>	Food Network
12		Decades	37		Outdoor Channel	63	<b>163</b>	Home & Garden Television
13	<b>113</b>	NBC - WEAU	38		Spike	64	<b>164</b>	Arts & Entertainment
14		Antenna TV	39		TBS	65		Lifetime
15		Hero's & Icon's	40		TNT	66		Comedy Central
16		Movies	41	<b>141</b>	FX	67		Freeform
17		Weather Channel	42		CNN	68		Nickelodeon
18		HSN	43		Headline News	69		The Disney Channel
19		QVC	44	<b>144</b>	FOX News	70		Disney XD
20		Shop HQ	45		FOX Business	71		MTV
21		CSPAN	46		CNBC	72		VH1
22		CSPAN 2	47		Cartoon Network	73		CMT
23		EWTN	48		TRU TV	74		Great American Country
24		Trinity Broadcast Network	49	<b>149</b>	The History Channel	75		Spare (future use)
25		Escape	50		Animal Planet	76		Investigative Discovery
			51		Discovery	77		The Science Channel
			52	<b>152</b>	National Geographic Ch.	78		Discovery Family

**Digital Tier \$12.45 - Must Have Expanded Basic**

202		OWN	210		VH1 Classic	220		Fuse
203		Game show Network	211		Spare (future use)	221		MTV2
204		Lifetime Movie Network	214		FXX	222		Teen Nick
205	<b>305</b>	DIY Network	216		Nick Jr	223	<b>323</b>	Cooking Channel
206		Destination America	217		FYI	224		FX Movie Channel
208		American Heroes Channel	218		Viceland	225		Discovery Life
209		CMT Music	219		Spare (future use)	226		Nick Toons
						227		Bloomberg

**Premiums Prices Vary- Call**

33		NFL RedZone	410		Showtime (East)	421		Starz (West)
400		MAX East	411		Showtime (West)	422		Starz Edge (East)
401		MAX West	412		Showtime Too East	423		Starz Encore (East)
402		MoreMAX East	413		Showtime Showcase W	424		Starz Encore (West)
403		MoreMAX West	414		Showtime Showcase E	425		Starz Encore Action (East)
404		HBO East	415		Showtime Extreme E	426		Starz Encore Action (West)
405		HBO West	416		Showtime Extreme W	427		Starz Encore Love (East)
406		HBO Family East	417		The Movies Channel E	428		Starz Encore Mystery (East)
407		HBO Family West	418		TMC Extra (East)	429		Starz Encore Drama (East)
408		HBO 2 East	419		TMC Extra (West)	430		Starz Encore Drama W
409		HBO Signature East	420		Starz (East)	431		Starz Encore Westerns E

**Digital Music Included With Expanded Basic**

900	Beautiful Instrumentals	910	80s Hits	920	Holidays & Happenings
901	Jazz Vocals	911	70s Hits	921	Great Standards
902	Hottest Hits	912	Classic R & B	922	Golden Oldies
903	Modern Country	913	Traditional Country	923	Reggae
904	Alternative Rock	914	Soft Hits	924	Children's
905	Coffeehouse Rock	915	Retro Disco	925	Adult Contemporary
906	Dance	916	Acid Jazz	926	Lite Classical
907	Contemporary Christian	917	Big Band/Swing	927	Rock-n-Roll Oldies
908	Album Rock	918	Smooth Jazz	928	Classic Rock
909	Hard Rock	919	New Age	929	Urban Beat